

**CANBUSLINE car alarm - for cars with CANBUS-electronics**  
 which are operated by the original remote control of the car (central locking)

TOBÉ GmbH  
 Weissenburger Str. 8 - 12, D-52068 Aachen  
 Tel.: + (0)241 5353-50 / Fax: -59  
 www.tobe-online.com



**Software:** The alarm is connected by an adapter to a PC, in order to **configure it to the car model..** The **parameter-file** (identified by the **code** listed here) to be saved in the alarm can be selected according to ex-works adjustments required, like:-  
**840 AD04** = horn-alarm for **Audi A2** = acoustic **alarm signals by horn**,  
**840+55...** = **additional modules to be controlled** (and alarm by horn),  
**840....taxi** = **taxi-alarm-function** (additional to traditional horn-alarm), or  
**851....** = siren-alarm = acoustic **alarm signals by siren**.  
**A840....** = ... **featuring notes in English language**.

**Software and fitting-manuals (with photos)** are supplied on a CD together with the **adapter**, respectively by e-mail (updates) or can be downloaded from Internet.

**Installation:** Only **5 - 8 wires** of the car must be connected, among them +30, +15, -31, and 2 CANBUS-wires. Further wires (i.e. for immobilizer, 'taxi-alarm', additional sensors,...) can - but must not - be connected..

The **PTL-device fits into all car models except Opel and Chevrolet (OP-device)**. If horn is triggered by ground, a jumper on the PCB must be set.

The **alarm-device's version (defined by its eeprom) must be higher or equal to the software-version, otherwise the alarm-device cannot memorize the software!**

**Available right now (04.09.2008) are the alarm versions: PTL up to 6.17 --- OP up to 6.17**

Software and fitting manuals for further car models will be available soon.

Parameter-files **XYmn-taxi** providing **TAXI-alarm-function** (additionally to normal car-aAlarm-function) are available, too, **for all car models**.

For car models marked by grey background there are available parameter-files **XYmn-i**, which provide arming and disarming of the car alarm (min. **6.17**) by the **KEYLESS-ENTRY** system (transponder-key) of the car model.

**car model since... to software version**

car model	since... to	software version
<b>MERCEDES</b>		
A - w169	2004...	ME04 3.0
B - t245	2005...	ME04 3.0
C - w203	2001-2006	ME01 3.0
CLK - c209	2003...	ME01 3.0
E - w211	2003-2006	ME01 3.0
E - w211	2007...	ME01A/B 3.0
ML - w164	2005...	ME05 6.6
R - w251	2005=>	ME01 3.0
S - w220	2003-2005	ME02 3.0
SLK - r171	2004...	ME01 3.0
Sprinter	2006...	ME06 3.0
Viano WDF	2004...	ME07 3.0
Vito	2001-2003	ME03 4.2
Vito WDF	2004...	ME07 3.0
<b>NISSAN</b>		
Micra	2005...	NI02 6.9
Navara	2007...	NI05 6.12
Note	2006...	NI01 6.9
Qashqai	2007...	NI03 6.12
Tiida	2007...	NI06 6.17
X-Trail	2007...	NI043 6.12
<b>OPEL</b>		
Antara	2007...	OP06 ■ 6.13
Astra H	2001-2004	OP01 ■ 4.4
Astra H	2005...	OP02 ■ 4.4
Astra H	2005...	OP05 ■ 6.10
Corsa D	2006...	OP04 ■ 6.8
Signum	2003...	OP01 ■ 4.4
Vectra	2002...	OP01 ■ 4.4
Zafira	2005...	OP03 ■ 4.4
Zafira	2006...	OP05 ■ 6.10
<b>PEUGEOT</b>		
207	2006...	PE01★ 6.6
307	2005...	PE02★ 6.6
407	2005...	PE03★ 6.6
Boxer	2006...	PE04 6.4
Expert	2006...	PE05★ 6.6
Partner	2006...	PE06★ 6.6
<b>PORSCHE</b>		
997	2005...	PO02 6.3
998	2006...	PO03 6.3
Cayenne	2003...	PO01 6.3
<b>SEAT</b>		
Altea	2004-2005	SE01 4.1
Altea	2006...	SE01N 6.5
Cordoba	2005...	SE05 6.5
Ibiza	2003...	SE02 5.2
Leon	2005...	SE03 6.5
Toledo	2005...	SE04 6.5
<b>SKODA</b>		
Fabia	2000-2006	SK03 6.5
Fabia	2007...	SK06 6.5
Octavia	2004-2005	SK01 4.1
Octavia	2006...	SK02 6.5
Roomster	2006...	SK05 4.1
Superb	2005-2008	SK04 6.5
Superb	2008...	SK07 6.5
<b>TOYOTA</b>		
Auris	2007...	TO02 6.6
Rav4	2006...	TO01 6.6
Yaris	2007...	TO03 6.6
<b>VW</b>		
Beetle	2001...	VK03 4.1
Bora	2001...	VK03 4.1
Caddy (2K)	2004...	VK08 6.1
Caravelle	2003...	VK07 6.5
Crafter	2006...	VK09 3.0
Eos	2006...	VK01N 6.1
Golf 4	1999-2003	VK03 4.1
Golf 5	2004...	VK01N 6.1
Golf Plus	2005...	VK01N 6.1
Jetta	2005...	VK01N 6.1
Passat (3B)	1999-2004	VK03 4.1
Passat (B6)	2005...	VK05 5.2
Polo (6N)	1999-2002	VK02 4.1
Polo (9N)	2003...	VK04 4.1
Touareg	2003-2005	VK06 6.0
T5	2003...	VK07 6.5
Tiguan	2007...	VK10 6.1
Touareg	2006...	VK06N 6.9
Touran	2003-2005	VK01 4.1
Touran	2006...	VK01N 6.1
Transporter	2003...	VK07 6.5

■ These Opel and Chevrolet car models require the special OP alarm device

**car model since... to software version**

<b>ALFA ROMEO</b>	159 -	2005...	AR01 6.5
	Brera	2006...	AR02 6.5
	Spider	2006...	AR03 6.5
<b>AUDI</b>	A2	2001-2005	AD04 4.1
	A3	2003...	AD01 4.2
	A3 Sport-Back	2004...	AD01 4.2
	A4	2002-2003	AD02 3.0
	A4	2004-2007	AD03 5.2
	A4	2008...	AD09 6.17
	A5	2007...	AD08 6.17
	A6	2004...	AD05 6.3
	A6	2006...	AD05N 6.3
	Q7	2006...	AD06 6.3
	TT	2006...	AD07 6.5
<b>BMW</b>	1 - E87	2004...	BM01 6.2
	3 - E90	2005...	BM01 6.2
	5 - E60	2003...	BM01 6.2
	6 - E63	2006...	BM01 6.2
<b>CHEVROLET</b>	Captiva	2006...	CH01■ 6.13
<b>CITROEN</b>	Berlingo	2006...	CI07★ 6.6
	C2	2005...	CI01★ 6.6
	C3	2005...	CI02★ 6.6
	C4	2005...	CI03★ 6.6
	C4 Picasso	2007...	CI04★ 6.6
	C5	2005...	CI04★ 6.6
	Jumper	2006...	CI05 6.4
	Jumpy	2006...	CI06★ 6.6
	Nemo	2008...	CI08 6.4
<b>FIAT</b>	Bravo	2007...	FI08 6.4
	Chroma	2005...	FI05 6.4
	Ducato	2006...	FI07 6.4
	Gran Punto	2005...	FI03 6.4
	Idea	2004...	FI02 6.4
	Linea	2007...	FI10 6.4
	Panda	2003...	FI01 6.4
	Scudo	2006...	FI09★ 6.6
	Stilo	2001-2005	FI04 6.4
	Stilo	2006...	FI06 6.4
	500	2007...	FI11 6.4
<b>FORD</b>	C-MAX	2003...	FO01 4.3
	Focus	2005...	FO02 4.3
	Mondeo	2007...	FO03 6.16
<b>INFINITY</b>	FX 35	2007...	IN03 6.17
	G 35	2007...	IN01 6.17
	M 35	2007...	IN02 6.17
<b>LANCIA</b>	Musa	2004-2007	LA02 6.4
	Musa	2007...	LA04 6.4
	Y	2003-2006	LA01 6.4
	Y	2006...	LA03 6.4

★ after installation the car alarm must be enabled in this car by OBD-tester!

TOBÉ GmbH  
 Weissenburger Str. 8 - 12, D-52068 Aachen  
 Tel.: + (0)241 5353-50 / Fax: -59  
 www.tobe-online.com

