

**car alarm**  
**(for all car models**  
**in case of need even with**  
**taxi-alarm-function)**

**Innovationprice 2002**  
**Automechanika (F/M)**  
category: autotronic  
1. Audi AG  
2. DaimlerChrysler AG  
3. **TOBÉ GmbH**

TOBÉ GmbH  
Weissenburger Str. 8-12  
D-52068 Aachen  
Tel. +49 (0)241 5353-50 Fax -59  
tobe-aachen@t-online.de  
www.tobe-aachen.de



suitable universally for all car models with digital **CANBUS** comfort electric

## CanBusLine can be fitted without any interface in....:

Alfa Romeo	159 (05-), Brera (i.p., 05-),...
Audi	A2 (01-05), A3 (03-), A3 Sportback (04-), A4 (-03. 04-), A5 (07-), A6 (04-), Q7 (06-),...
BMW	1 (04-), 3 (05-), 5 (03-), 6 (04-),.....
Chevrolet	■Captiva (06-),
Citroën	★Berlingo (06-), ★C2 (05-), ★C3 (05-), ★C4 (05-), ★C4 Picasso (07-), ★C5 (05-), Jumper (06-), ★Jumpy (06-), .....
Fiat	500 (07-), Bravo (07-), Chroma (05-), Ducato (06-), Gr. Punto (05-), Idea (04-), Linea (07-), Panda (03-), ★Scudo (06-), Stilo (01-05, 06-),.....
Ford	C-max (03-), Focus (05-), Mondeo (07-),.....
Infiniti	FX35 (07-), GX35 (07-), MX35 (07-), .....
Lancia	Musa (04-), Thesis (i.p. 05-), Ypsilon (03-05, 06),.....
Land Rover	Range Rover Sport (i.p., 05-),.....
Mercedes	A w169 (04-), B (05-), C w203 (01-07), CLK (03-), E w211 (03-06), E w211 (07-), ML w164 (05-), R (05-), S w220 (03-05), SL (i.p., 03-), SLK (04-), Sprinter (06-), Viano (04-), Vito (01-03, 04-),.....
Nissan	Micra (05-), Navara (07-), Note (06-), Qashqai (07-), . Tiida (07-), X-Trail (07-),...
Opel	■Antara (07-), ■Astra H (01-), ■Corsa C (06-), ■Signum (03-), ■Vectra (02-), ■Zafira (05-),.....
Peugeot	★207 (06-), ★307 (05-), ★407 (05-), Boxer (06-), ★Expert (06-), ★Partner (06-),.....
Porsche	911 (i.p., 06-), 997 (05-), 998 (06-), Boxster (i.p., 03-), Cayenne (03-),.....
Saab	903 (i.p., 05-),.....
Seat	Altea (04-05, 06), Cordoba (03-), Ibiza (02-), Leon (05-), Toledo (05-),.....
Skoda	Fabia (05-), Octavia (04-05, 06-), Roomster (06-), Superb (05-),.....
Toyota	Auris (07-), Rav4 (06-), Yaris (07-),.....
VW	Beetle (01-), Bora (01-), Caddy (04-), Crafter (06-), Eos (06-), Golf 4 (99-03), Golf 5 (04-), Golf Plus (05-), Jetta (05-), Polo (99-02, 03-), Passat (99-04, 05-), T5 (Caravelle) (03-), Tiguan (07-), Touran (03-05, 06-), Tuareg (03-),.....
Volvo	C70 (i.p., 06-), S80 (i.p., 06-), V50 (i.p., 05-),...

★ The CanBusLine alarm must be enabled in this car model by OBD-tester !

■ This car model requires the CanbusLine- device OP

17.01.2008. "i.p." = "in preparation": Software-updates with installer manuals for new car models will be provided continuously

## car model selection on PC

In situ the selected **vehicle parameter file** is simply stored into the CanBusLine device being connected to a PC. The required **COM-adapter** is supplied together with the **software**.

The selected "configuration" can be changed at any time. The PC-program-menu furthermore allows to arrange for **customized adjustments**, if desired, and provides helpful **service functions**, too.

## installer manuals...

....for every car model (with photos) are contained in the **software**. Continuously **updates** are provided for new car models, and are mailed, if requested

On account of considerable advantages (less wires and weight, free knot amount,...) all European car producers (except Renault), as well as Toyota and Nissan link already the comfort electric (roof, doors, bonnet, trunk, seats, remote, central locking,...) of their recent car models by **digital CANBUS**.

Therefore traditional (that is analogous) electric accessories cannot be retrofitted any more, except an (expensive) interface is available for the car model as well as the accessory.

## "universal":

All car models with **CANBUS-comfort-electronics** can be equipped with the CanBusLine-device. (Only Opel models require a special device).

## easy to install:

The CanBus links already the electric components of the car. Thus **only 5 - 8 wires** must be soldered, often all of them close to one central unit of the car. (Never cut a CanBus-wire. Simply take away a spot of its insulation.)

# CanBusLine car-alarm

operated by the original remote control of the car

E24 97R A-010034  
European Type Approval

- ★ monitoring: **door, boot, bonnet, ignition, parking-crash (shock-sensor),....**
- ★ alarm signals **by blinker as well as horn or siren**
- ★ alarm memory **can be read via sequences of LED-flashes**
- ★ pin-code **by turning on/off ignition disarms the alarm (if remote is defect, or...)**
- ★ blinker- and beep-confirmations **when arming or disarming the alarm**
- ★ immobilizer: **disables the engine electric in an "individual" manner**
- ★ 'intelligent': **simple mechanical opening of a door always triggers alarm, - but unlocking of the boot by remote control does not trigger alarm**
- ★ taxi-alarm **is possible additionally to the normal car-alarm-function**

**individual**

**secure**

**good value**

tentative price recommendation:  
**250 €+ installation**  
(appr. 1 - 2 hours)